

Installing Verts in Footing

*
12" for
10 inch Block

Advisory Only. Always Consult Your Structural Engineer Regarding Any Rebar Placement

