

7. Install Kickers & Zat brackets

- Screw Zuckle to kicker, attach to base of handrail upright.
- Double stake kicker to ground.
- Screw attach Zat bracket 3' from top of wall.
- Install 2x10 catwalk plank(s) as required.

Loosely attach so wall can still adjust

- Double check plumb & secure before tightening up bracing.

